



WIRING COLOR CODE

HOT	A	RED
MASTER	A <sub>1</sub>	RED-WHT
GRND	B	BLACK
R. WING	1	WHT - BLK - RED
	2	WHT - BLK - BLUE
L. WING	3	WHT - BLK - BRN
	4	WHT - PURPLE
SWING	5	WHT - BLK - YEL
	6	WHT - SIL
LIFT	7	WHT - BLUE
	8	WHT - BLK - GRN
PLUMP	9	WHT - GRN
	10	WHT - BRN - RED
	11	GREEN
	12	SILVER
	13	PURPLE
	14	WHITE
	15	WHT - BLK - SIL
BAR	16	BROWN
	17	BLACK
	18	YELLOW
	19	WHT - RED
	20	WHT - ORG
	21	WHT - BLK
	22	WHT - BRN
L.M.	23	BLUE
R.M.	24	WHT - YEL
EQUALIZER	25	ORANGE
BITUMETER	26	WHT - BLK - PURP
	27	YELLOW

Figure 6.7.  
Component Locations, Cab Control Panel